



HANDBAG/CLUTCH DISPLAY

\$41.80



SKU: 54167A

Stock: N/A

Categories: [Acrylic Display Risers | Easels, Jewelry Displays & Accessories](#)

PRODUCT DESCRIPTION

Clear Acrylic Plexiglass Handbag Display. Handbag Display Holds Seven Handbags.



ADDITIONAL INFORMATION

Size [18" long](#)

Color Finish [Acrylic](#)

